



Power Button- Turns gauge ON/OFF.

Cursor Button- Turns cursor and Ground Proximity Messages ON/OFF.

Range Markers- Places mileage marks at center of Screen, and displays NM scale.

Airport Button- Shows all airports and ICAO Identification on moving map.

Range Selector- Plus/minus arrow keys that change the nautical mile range limits of map.

Range Max Window- The NM distance from aircraft position to the top of screen.

Map Mode- Activates the moving map display.

Aircraft Position- When cursor is active, this tick indicates position of the aircraft.

Range Scale- Used to approximate distance from aircraft to objects on map.

Range Ticks- These correspond to the mileage numbers shown on the Range Scale.

Cursor- A horizontal course line at center screen with tick representing aircraft position.

Moving Map- The FS map that moves with a change in aircraft position.

Aircraft Icon- Indicates the altitude of aircraft.

Elevation Scale- Scale in ft. X 1000 showing the altitude of aircraft and elevation of ground.

Elevation Legend- Color blocks keyed to the tints used in the FS map.

Ground Elevation Ribbon- Indicates the elevation of ground below the aircraft.

Ground Proximity window- Distance from aircraft to ground to the nearest 50-feet.

Prox. Inc/Dec- Up Arrow, distance increasing. Down Arrow, distance decreasing.

Page Number- Indicates the page that is currently on the screen.

Page Scroll- Allows large pages to be moved both horizontally and vertically.

Page Reset- Returns a page to its default location on the TerraVue screen.

Page Selector- Buttons used to display page.

Page View- Graphic containing information such as aeronautical charts, checklists, etc.

Screen Messages

ALERT 800'

Ground proximity: 800-feet.

CAUTION 500'

Ground proximity: 500-feet.

WARNING 200'

Ground proximity: 200-feet.

ALT LIMIT

Aircraft altitude 16000 ft. plus.

ALT LIMIT

Aircraft altitude below MSL.