

## CrgWinKeys Reference

a	Toggle altitude hold
b	First Officer's Nav Display: decrease range
ctrl b	First Officer's Nav Display: increase range
o	First Officer's Nav Display: next mode
d	Toggle flight director
f	Toggle frame rate display on the instruments.
g	Toggle gear position
h	Toggle heading hold
j	Toggle VNAV
k	Toggle LNAV
l	Toggle approach hold
n	Toggle net stats mode
c	Captain's Nav Display: next mode
p	Toggle simulator pause
s	Toggle speed hold
t	Toggle thrust armed
u	Toggle autopilot on/off
v	Captain's Nav Display: decrease range
ctrl v	Captain's Nav Display: Increase range
x	Auto Thrust: Speed + 1
ctrl x	Auto Thrust: Speed + 10
z	Auto Thrust: Speed – 1
ctrl z	Auto thrust: Speed - 10
right arrow	AP heading: Right 1 degree
ctrl right arrow	AP Heading: Right 10 degrees
left arrow	AP Heading: Left 1 degree
ctrl left arrow	AP Heading: Left 10 Degrees
up arrow	AP Altitude: Up 100 feet
ctrl up arrow	AP Altitude: Up 1000 feet
down arrow	AP Altitude: Down 100 feet
ctrl down arrow	AP Altitude: Down 1000 feet
function key 2	Toggle instrument setup (select instrument first)
function key 3	Reset flight plan
function key 4	Toggle chart range high/low
function key 5	Toggle TO/GA
function key 6	Flaps up one increment
function key 7	Flaps down one increment
1	Display WAC Charts (see docs)
2	Display Small TAC Charts (see docs)
3	Display Large TAC Charts (see docs)
4	Display VFR Charts (see docs)

Note: One of the CrgWinKeys windows must be selected for these keys to affect CRG/FSX operation.